

SPECIFICATIONS FOR MANUFACTURING SHADES AND BLINDS TO BE DROP SHIPPED TO AM-SOURCE FOR MOTORIZATION

Cellular and Pleated Shades

1. Headrail and bottomrail should be same width as the fabric.
2. Shade fabric must be attached to headrail and bottomrail.
3. Fabric is to be pre-punched or pre-drilled with route holes.
Pleated shades cannot have end route holes less than 1½" from the end of the headrail.
Motor placement requires one opening, preferably centered on headrail, Minimum of 15" between route holes. (See page 5)
4. Grommets to be installed in headrail above route holes for lift tapes (if necessary).
5. Tape locking plugs and sleeves are to be installed in bottomrail.
6. No cord locks are necessary on motorized treatments.
7. No cords – Am-Source is to use 3/32" lift tape.
8. Send manufacture's brackets with shade.
9. All mounting brackets are supplied with motorized headrail.
10. Attaching shade to headrail charges apply:

Cellular shade	\$45.00 each
Pleated shade	\$55.00 each
11. Allow minimum ½" space between shades if multiple shades on one headrail.

Note: Certain cellular shades need to be ordered (supplied) longer than the window opening because of fabric memory. Please call Am-Source before ordering.

Horizontal and Wood Blinds

1. Order complete blinds 10" longer than required, *OR* if ordering slat pack, order ladderbraid 10" longer than measured drop.
2. Motor placement requires one opening, preferably centered on headrail, minimum of 15" between route holes and/or ladderbraids. (See page 5)
3. Include tape locking plugs and sleeves in bottomrail.
4. Route holes are required at each Ladderbraid / Decorative Tape location
5. Attaching blinds to headrail charges apply. Charge to attach \$55.00.
6. All above items are per blind, even for multiple shades on one headrail.
7. Attach COM Decorative ladders. Charge to attach \$25.00 per ladder.
8. Allow minimum ½" space between blinds if multiple blinds on one headrail.

Roman Shades and Woven Woods

1. Motor placement requires one opening, preferably centered on headrail, minimum of 15" between route holes. (See page 5) (If spacing must be closer, consult Am-Source for options).
2. Lift tapes cannot be less than 1½" from the ends of the headrail.
3. Am-Source is to use 3/32" lift tape.
4. Attach Roman to 1" x 3" board
5. Attaching shade to headrail charges apply. Charge to attach \$55.00.
6. Special Roman Shade brackets available at additional charge.

All labor charges are net. Additional charges may apply if shades or blinds are oversize or if not manufactured to the above specifications. Please contact Am-Source for further support.