



Adjusting Motor Limits LT28



1. Determine the rotation of the roller shade for each direction.




Counter Clockwise for
Down Direction



Clockwise for
Down Direction

2. Locate limit switch push buttons on motor and match the limit arrow (direction indicator) with the direction to be adjusted.



3. With power supplied to motor (shade) use a small "bladed" screwdriver to depress the limit switch adjuster buttons.

To increase the amount of shade travel in given direction, depress the limit button which corresponds to the direction of rotation.

To reset limit adjustments, Simply depress each limit button until a "click" sound heard. (Button will remain fully engaged). Continue to depress button until a second click sound is heard, push button will return to it's normal state. (Limit will be reset for that direction)

Repeat process to reset other direction...

For more information contact:

Am-Source International 1550 Old Rand Road, Unit A Wauconda, IL 60084 Phone: 1.800.876.7367